

**Quick Installation Guide** 

# INTRODUCTION

The AW-GET-123A-240 is a 8 port 10/100/1000BaseT PoE switch capable of feeding 15.4/30W (54V max. per port) power to Power over Ethernet (PoE) devices. It comes with another 4x GbE SFP port. The switch is capable of a total of 240 Watts PoE power budget.

### PACKAGE CONTENTS

* 1x PoE switch	* 1x Quick Installation Guide
* 1x T25 L-wrench, 4x wall anchors	

#### MIMPORTANT:


1. Install the PoE switch in a ventilated and dry place that is free of electromagnetic source, vibration, moisture, and dust.

2. Make sure the ventilation openings on the switch are not blocked.

3. Use CAT5 or 5e UTP/STP cables.

4. AC input (100~240V/AC, 50~60Hz), for a max. consumption of 250W.

# CONNECTION



### LED DEFINITIONS

Power1	Green ON	Power is on and normal.		
	Green Off	The switch is not receiving power.		
Power2	Green ON	Power is on and normal.		
	Green Off	The switch is not receiving power.		
RJ45 ports	Green ON	Port is enabled and link established with a device at the 1000Mbps speed.		
LED1	Grren Blinking	Port is transmitting and receiving data at the 1000Mbps speed.		
	Amber ON	Port is enabled and link established with a device at the10/100Mbps speed.		
	Amber Blinking	Port is transmitting and receiving data at the 100Mbps speed.		
	Off	No active network connection. The port may have been disabled through user interface.		
RJ45 ports LED2	Green ON	The port is enabled and supplying power to connected device.		
	Amber ON	An abnormal state, such as overload status has occurred.		
	Off	The port has no active network cable connected, or it is not connected a PoE PD device. Otherwise, the port may have been disabled through the switch user interface.		
SFP ports	Green ON	Port is enabled and link established with a device at the 1000Mbps speed.		
	Grren Blinking	Port is transmitting and receiving data at the 1000Mbps speed.		
	Amber ON	The port is enabled and established a link to connected device, and the connection speed is 100Mbps.		
	Amber Blinking	Port is transmitting and receiving data at the 100Mbps speed.		
	Off	No active network connection. The port may have been disabled through user interface.		


ההההההה

# **RESET & RESTORE**


Reset the switch	2 ~ 7 seconds	Blinking Green	All LEDs off
Restore to defaults	7 ~ 12 seconds	Blinking Green	All LEDs ON


# INSTALLATION

Use the included M10 hex socket screws to secure the power box to a pole-mount or corner mount bracket.



The mounting hole definition is illustrated below. The same mounting hole pattern apply to all pole-mount and cornermount brackets.





All specifications are subject to change without noice. Copyright © 2017 VIVOTEK INC. All rights reserved.

#### VIVOTEK INC.

6F, No.192, Lien-Cheng Rd., Chung-Ho, New Taipei City, 235, Taiwan, R.O.C. |T: +886-2-82455282 | F: +886-2-82455532 | E: sales@vivotek.com VIVOTEK USA, INC.

2050 Ringwood Avenue, San Jose, CA 95131 |T: 408-773-8686 |F: 408-773-8298 |E: salesusa@vivotek.com VIVOTEK Europe Randstad 22-133, 1316BW Almere, The Netherlands T: +31(0)36-5298-434 E: saleseurope@vivotek.com